


English


IMPORTANT: Please connect the Actipaper reader to your computer **AFTER** the driver installation.


Installation:


- 1 Open your Web browser and go to www.actipaper.com;
- 2 In the download section, click on the appropriate link for your operating system (Windows or Mac);
- 3 Run the installation program and follow the on-screen instructions;
- 4 When the driver installation is complete, connect the reader. After a few seconds, a black icon  appears to inform you that the reader is ready to use.
 - On Windows, you will find it in the notification area of your taskbar, which is usually located at the bottom right of your screen;
 - On Mac, this icon appears in the menu bar, in the top left-hand corner of your screen.

Nota bene : The icon is red  when the reader is not connected to the computer.

Use:

The reader that you have installed lets you connect to the Internet simply by scanning an "Actipaper compatible" code. These codes always look as follows: 

In some cases, the code may be accompanied by an icon  that describes the type of associated content (Read more, Video, etc.).

- 1 When you want to use the Actipaper solution to connect directly to the Internet content associated with a code, follow the steps below:
- 2 Position the reader over the Actipaper code so that the entire code appears in the reader sighter located on the button extension.
- 3 Click the button once to activate the reader, which turns the icon from black to yellow .

The system then automatically launches your Web browser (if it is not already open) and directly displays the Web content associated with the code. The icon changes colour again  to indicate that the code has been successfully read.

Important:

The system does not alter either how long your Web browser takes to open or the display time of the website to which the Actipaper code links. If the website contains a high number of images or if you connect to a video, you may have to wait while the page opens.

Troubleshooting:

If you have problems with the reader, make sure that:

- You have the correct driver for your operating system;
- The driver is correctly installed on the computer (if necessary, uninstall the driver then reinstall it);
- The reader is correctly connected to a 2.0 USB port on the computer;
- The computer's Internet connection is working properly;
- The whole code appears in the reader's sighter;
- The code is in fact "Actipaper compatible"

The Actipaper reader is guaranteed against any manufacturing defects for a period of one year starting from the date of delivery. If after carefully following the instructions in this guide you find that your reader is faulty, you may return it by freepost to the following address:

Actipaper - Service consommateur - 10, rue Blanqui
93406 SAINT-OUEN CEDEX - FRANCE